


Beschreibung der Anschlussklemmen der alten und neuen Elmo Rietschle FU

Steuerklemmen-Modul 2FX4501-0NE00




Klemme/ Kontakt	Signaltyp	Funktion
X3/62	Analoger Ausgang	Ausgangsfrequenz
X3/7	GND1, Bezugspotential für analoge Signale	
X3/8	Analoger Eingang	Sollwerteingang Sollwertbereich umschalten mit DIP-Schalter
X3/9		Interne, stabilisierte DC-Spannungsquelle für das Sollwertpotentiometer +5,2 V (Bezug: X3/7)
X3/7	GND1, Bezugspotential für analoge Signale	
X3/20		Interne DC-Spannungsquelle zum Ansteuern der digitalen Eingänge und der digitalen Ausgänge +20 V ± 10 % (Bezug: X3/7)
X3/28	Digitale Eingänge	Regler-sperre Störung zurücksetzen (TRIP-RESET) Externe Störung Aktivierung von Festdrehzahlen
X3/E1		
X3/E2		
X3/E3		
X3/E4		
X3/39	GND2, Bezugspotential für digitale Signale	
X3/A1	Digitaler Ausgang	Meldung "Betriebsbereit"
X3/59	DC-Versorgung für X3/A1	



Neuer Elmo Rietschle Frequenzumrichter



Klemme/ Kontakt	Signaltyp	Funktion
X5/15	A. Out 0 ... 10 V	Frequenz-Istwert (Parameter 4.100)
X5/16 X5/18 X5/20	A GND (Ground 10 V)	Masse
X5/17	A. In 1	Ext. Sollwertquelle (parameter 1.130)
X5/14	10 V Out	Für ext. Spannungsteiler
X5/16 X5/18 X5/20	A GND (Ground 10 V)	Masse
X5/3 X5/5	24 V Out	Int. Spannungsversorgung
X5/6	Dig. In 1	Software-Freigabe (Parameter 1.131)
X5/8	Dig. In 3	Fehler Reset (Parameter 1.180)
X5/9	Dig. In 4	Externer Fehler (Parameter 5.010)
X5/6	Dig. In 1	Festfrequenz 1/3 (Parameter 1.100)
X5/7	Dig. In 2	Festfrequenz 2/3 (Parameter 1.100)
X5/2 X5/4	GND (Ground)	Masse
X5/11	Dig. Out 1	Bereit (Parameter 4.150)
X5/12	Dig. Out 2	Betrieb (Parameter 4.170)
nicht vorhanden, intern verklemmt		




Documentation of connection terminals of OLD and NEW Elmo Rietschle Drives


Connection Modul 2FX4501-0NE00



Terminal No.	Signal Type	Function
X3/62	Analog output	Output frequency
X3/7	GND1, reference potential for analog signals	
X3/8	Analog input	Setpoint input Change setpoint selection range via DIP switch
X3/9		Internal, stabilised DC voltage source for setpoint potentiometer +5.2 V (ref: X3/7)
X3/7		GND1, reference potential for analog signals
X3/20		Internal DC voltage source to control digital inputs and digital outputs +20 V ± 10 % (ref: X3/7)
X3/28	Digital Inputs	Controller inhibit Reset fault (TRIP-Reset) External fault Activation of fixed speeds
X3/E1		
X3/E2		
X3/E3		
X3/E4		
X3/39		GND2, reference potential for digital signals
X3/A1	Digital Output	"Pulse inhibit active" message
X3/59		DC supply for X3/A1




New Elmo Rietschle VFD



Terminal No.	Signal Type	Function
X5/15	A. Out 0 ... 10 V	Actual frequency (parameter 4.100)
X5/16 X5/18 X5/20	A GND (Ground 10 V)	Ground
X5/17	A. In 1	Reference channel (parameter 1.130)
X5/14	10 V Out	For ext. voltage divider
X5/16 X5/18 X5/20	A GND (Ground 10 V)	Ground
X5/3 X5/5	24 V Out	Int. power supply
X5/6	Dig. In 1	Software release (parameter 1.131)
X5/8	Dig. In 3	Reset (parameter 1.180)
X5/9	Dig. In 4	External fault 1 (parameter 5.010)
X5/6	Dig. In 1	Preset speed 1/3 (parameter 1.100)
X5/7	Dig. In 2	Preset speed 2/3 (parameter 1.100)
X5/2 X5/4	GND (Ground)	Ground
X5/11	Dig. Out 1	Ready for operation (Parameter 4.150)
X5/12	Dig. Out 2	Ready (Parameter 4.170)

arranged by internal supply




Beschreibung der Anschlussklemmen der alten und neuen Elmo Rietschle FU



Applikations-Modul 2FX4502-ONE00



Neuer Elmo Rietschle Frequenzumrichter



Klemme/ Kontakt	Signaltyp	Funktion	Klemme/ Kontakt	Signaltyp	Funktion
X3.1/1U X3.1/2U	Analoge Eingänge	Spannungseingänge für Istwerte oder Sollwerte	X.5/17	A. In 1	Ext. Sollwertquelle (parameter 1.130)
X3.1/1I X3.1/2I		Stromeingänge für Istwerte oder Sollwerte	X.5/19	A. In 2	PID-Istwert (Parameter 3.060)
X3.2/62	Analoge Ausgänge	Ausgangsfrequenz	X.5/13	A. Out 0 ... 20 mA	Frequenz-Istwert
X3.2/63		Motorstrom	X.5/15	A. Out 0 ... 10 V	(Parameter 4.100)
X3.2/9	Interne, stabilisierte DC-Spannungsquelle für das Sollwertpotentiometer +5,2 V (Bezug: X3.3/7)		X.5/13	A. Out 0 ... 20 mA	Frequenz-Istwert
X3.3/A1	Digitale Ausgänge	Betriebsbereit	X.5/14	10 V Out	Für ext. Spannungsteiler
X3.3/A2		Nicht konfiguriert	X.5/11	Dig. Out 1	Bereit (Parameter 4.150)
X3.3/7	GND, Bezugspotential		X.5/12	Dig. Out 2	Betrieb (Parameter 4.170)
X3.3/7			X.5/18	A GND (Ground 10 V)	Masse
X3.3/A4	Frequenz- ausgang	Zwischenkreisspannung	X.5/20		
X3.3/59	DC-Versorgung für X3.3/A1 und		X.5/	nicht vorhanden	
X3.3/20	Interne DC-Spannungsquelle zum Ansteuern der digitalen Eingänge und der digitalen Ausgänge +20 V ± 10 % (Bezug: X3.3/7)		X.5/1	24 V In	Ext. Spannungsversorgung
X3.3/28	Digitale Eingänge	Reglersperre	X.5/5	24 V Out	Int. Spannungsversorgung
X3.3/E1		JOG1	X.5/6	Dig. In 1	Software-Freigabe (Parameter 1.131)
X3.3/E2		JOG2	X.5/6	Dig. In 1	Festfrequenz 1/3 (Parameter 1.100)
X3.3/E3		Gleichstrombremse	X.5/7	Dig. In 2	Festfrequenz 2/3 (Parameter 1.100)
X3.3/E4		Drehrichtung umschalten	X.5/8	Dig. In 3	Fehler Reset (Parameter 1.180)
X3.3/E5		Nicht konfiguriert	X.5/9	Dig. In 4	Externer Fehler (Parameter 5.010)
X3.3/E6		Nicht konfiguriert	X.5/13	A. Out 0 ... 20 mA	Frequenz-Istwert (Parameter 4.100)
			X.5/15	A. Out 0 ... 10 V	Frequenz-Istwert (Parameter 4.100)




Documentation of connection terminals of OLD and NEW Elmo Rietschle Drives

Application Modul 2FX4502-0NE00




Terminal No.	Signal Type	Function
X3.1/1U X3.1/2U	Analog Inputs	Current inputs for actual values or setpoints Stromeingänge für Istwerte oder Sollwerte
X3.2/62 X3.2/63	Analog Outputs	Output frequency Motor current
X3.2/9		Internal stabilised DC voltage source for the setpoint potentiometer +5.2 V (ref: X3.3/7)
X3.3/A1 X3.3/A2	Digital Inputs	Ready for operation Not configured
X3.3/7 X3.3/7		GND, reference potential
X3.3/A4	Frequency Output	DC bus voltage
X3.3/59		DC supply for X3.3/A1 and X3.3/A2
X3.3/20		Internal DC voltage source for control of the digital inputs and digital outputs +20 V ± 10 % (ref: X3.3/7)
X3.3/28 X3.3/E1 X3.3/E2 X3.3/E3 X3.3/E4 X3.3/E5 X3.3/E6	Digital Inputs	Controller inhibit Activation of fixed speeds DC injection brake (DCB) Reverse direction of rotation Not configured Not configured



New Elmo Rietschle VFD



Terminal No.	Signal Type	Function
X.5/17	A. In 1	Reference channel (parameter 1.130)
X.5/19	A. In 2	PID feedback (parameter 3.060)
X.5/13 X.5/15 X.5/13 X.5/6	A. Out 0 ... 20 mA A. Out 0 ... 10 V A. Out 0 ... 20 mA Dig. In 1	Actual frequency (parameter 4.100) Actual frequency (parameter 4.100) Actual frequency (parameter 4.100) For ext. voltage divider
X.5/11 X.5/12	Dig. Out 1 Dig. Out 2	Ready for operation (Parameter 4.150) Ready (Parameter 4.170)
X.5/18 X.5/20	A GND (Ground 10 V)	Ground
X.5/	nicht vorhanden	
X.5/1 X.5/5	24 V In 24 V Out	Ext. power supply Int. power supply
X.5/6 X.5/6 X.5/7 X.5/8 X.5/9 X.5/13 X.5/15	Dig. In 1 Dig. In 1 Dig. In 2 Dig. In 3 Dig. In 4 A. Out 0 ... 20 mA A. Out 0 ... 10 V	Software release (parameter 1.131) Preset speed 1/3 (parameter 1.100) Preset speed 2/3 (parameter 1.100) Reset (parameter 1.180) External fault 1 (parameter 5.010) Actual frequency (parameter 4.100) Actual frequency (parameter 4.100)



Beschreibung der Relais der alten und neuen Elmo Rietschle FU /
Documentation of relays of OLD and NEW Elmo Rietschle Drives


K11 K14



K11 K14



K11 K14




ALT / OLD

Netz aus /
mains off


Netz ein /
mains on

Fehler aktiv /
TRIP active


NO NC



NO NC



NO NC



NEU / NEW